FOSCAM

Quick Installation Guide

Indoor HD Wireless IP Camera with P2P

Model:FI9816P

Black

White

"Foscam" App download

Foscam Digital Technologies

V1.0
EE200470

Package Contents

IP Camera

Power Adapter

Resource CD

Ethernet Cable

Mounting Bracket

Wi-Fi Antenna

Quick Installation Guide

Security Warning Card

Security Warning

- **Foscam cameras require good security practices to safeguard your privacy. You can help protect your camera by changing the default username and/or password.**
- **You should update your camera regularly at http://www.foscam.us/firmware.html. Make sure your camera has the latest firmware installed for your specific camera model.**

1 Hardware Introduction

● Physical Description







The Information of Network Light Status:

Network Light	Description
Off	No Wi-Fi connection
Flashing every 0.2 seconds	EZLink takes effect (default)
Flashing every 0.4 seconds	WPS is connecting
Slow Flash once per second	Wi-Fi connected
Constant for 3 seconds	Reset to take effect

● Hardware Connection





1. Install wireless antenna and position upright.
2. Connect the power adapter to the camera.
3. Turn on your wireless router.

Before you start, please note:

- Make sure your smartphone is located near the camera.
- Do not use an ethernet cable to connect the camera if you want to use a wireless connection.
- Make sure smartphone is connected to your wireless router.

2 Access the IP Camera by Smart Phone

1. Download and install the latest Foscam App named **Foscam**.

Two ways:

- Scan the QR code of the Quick Installation Guide front cover to enter the download page, download and install Foscam App.
- Go to App Store or Google Play store to search “Foscam” by Foscam, download and install Foscam App.

The App icon will be displayed after successful installation:

Please Note:

If you are directed to a link for both iOS/Android after you have scanned the QR code, click on the link to be directed to the relevent App store.

2. Once you have successfully installed the Foscam App, launch the App and login to the Foscam Cloud. If you do not have an account, please select “Sign up”to create your account.

3. Now you have logged in to your Foscam Could account you may add your camera, press the add camera button and follow on screen prompts to scan the QR Code located beneath your camera.



Add New Camera
QR UID
DDNS
IP Address
If there is QR code on your device, please click the button above to scan the QR code to add your device; otherwise please use DDNS or IP Address tab instead.
If it is not convenient to use QR code, you can manually enter QR code UID here.
QR Code UID
Next

Follow the scanning of the camera QR code via EZLink connection, the QR Code UID should now be auto populated. Follow steps below to connect your camera to your wireless network.


Add New Camera
QR UID
DDNS
IP Address
If there is QR code on your device, please click the button above to scan the QR code to add your device; otherwise please use DDNS or IP Address tab instead.
If it is not convenient to use QR code, you can manually enter QR code UID here.
QR Code UID
EXGTAADYNLYRBGPMYR3JA198
Next



a. Camera’s default username are **admin** and (**blank**).
b. Input the **New password** of your camera.
c. Input the **Password** of your wireless router.
d. Click "CONNECT".



Add successfully: Enter the operation page.


EZLink Wi-Fi connection
QR Code UID
EXGTAADYNLYRBGPMYR3JA198
Sorry, your camera has failed to be added.
Please make sure your camera is within the range of the wireless router.
Please check whether the Wi-Fi password is correct.
OK
CONNECT

Failed to add: Please confirm the password of wireless router or camera, then re-add.

4. After your camera is added successfully, you can access it any where and any time via App or Foscam Cloud Service.

3 *FAQ*

Forgot Username / Password

Restore camera back to factory settings:

1. Press "Reset" button for about 10 seconds with camera energized.

2. Release the button and wait about 30 seconds, the camera will automatically restart, and restore factory settings with its username / password recovery to admin / blank (you need to re-connect Wi-Fi).

Please Note:

- After restore to factory default settings, the default connection is EZLink mode.
- Plug the ethernet cable, switch to wired connection mode. Please refer to the User Manual in the CD about wired connection.
- In case your device failed to add via EZLink mode, you can use WPS mode or wired connection. Please refer to the User Manual on the CD.

4 *Technical Support*

We hope your experience with the Foscam IP camera is enjoyable and easy to use. If you experience any issues or have any questions that this Quick Installation Guide has not answered, please contact our support department via the websites listed below 24 hours a day, 7 days a week.

FOSCAM

Foscam Digital Technologies

www.foscam.us www.foscam.ca www.foscam.co.uk
www.foscamgroup.com www.foscam.com